


Automatic die head 1/2-2"

No. 56266_56271

dated: 09/17



Größe/size				No. SS- steel	No. HSS- steel
BSPT R	1/2-2"	56266	1/2-3/4"	56003	56235
			1- 2"	56007	56236
NPT	1/2-2"	56271	1/2-3/4"	56111	56180
			1-2"	56112	56181

Automatic die head 1/2-2"

dated: 09/17

No. 56266_56271

Item no.	Description	Article no.	Quantity
1	stop bolt 6x25	H98368	4
2	spring washer 6	81621	4
3	Retaining ring AT SC 2SE	1500002190	1
4	parallel pin 12x10	86026	1
5	opening spring	86027	1
6	stop bolt 5x10	86028	3
7	location plate	86029	2
8	steel ball 3/16"	83485	2
9	location spring	83486	2
10	BE Set block PT 1/2"-2" S	1500000245	1
11	spring pin 6x20	84191	2
12	button bolt 10x45	86031	1
13	washer 10	86032	1
14	hex cap nut 10	86033	1
15	stop bolt M8x18 *	83899	6
16	location block M8 *	83900	6
17	T-handle	86482	1
18	spring washer 5	84094	1
19	Cam Plate M8 with scala AS 1/2-2" *	83922	1
20	cylinder head screw M6x15	83489	8
21	ring plate 1/2-2"	83490	1
22	lever spring	86040	1
23	set pin	86041	1
24	Locking lever	1500002192	1
25	hex nut 10	86043	1
26	die head body SC 2SE 1/2"-2"	86048	1
27	spring pin 8x32	85791	1
28	Scale BSPT AT	1500002193	1
29	spring	86040	1
30	plate tack	83622	5
31	spring washer 8-1 *	83923	6
32	spring pin 4x16	86047	1
33	Spring washer M2	1500002194	1
34	Locking Sleeve 6x16	1500002195	1
35	ball cap	83601	1

IMPORTANT! To assure safety and reliability, repairs, maintenance and adjustment must be preformed by ROTHENBERGER Kelkheim or authorized Service-Centers. Always use Original-Service-Parts. Order your accessories and spare parts from your specialist retailer or using our Service After Sales hotline

Tel. +49 6195 - 800 **8200**

Fax: +49 6195 - 800 **7491**

 service@rothenberger.com