ROTHENBERGER

FREEZE-PAK INSTANT PIPE FREEZING KIT

Produces an ice plug in 10 minutes that will last upto 30 minutes

(dependent on water and room temperature)

- Quick and easy to use
- No need to drain down
- Will freeze copper, lead, steel & plastic pipes
- Size range Ø 8 28 mm (5/16"-1")
- Can be used on horizontal & vertical pipes
- Safe to use CFC free
- Ideal solution for emergency repairs
- Kit contains:
 500g Can of Quick Freeze spray
 2 Quick Freeze jackets, 4 Cable ties



CFC

FREE

Quick Freeze

or Spra

ROTHENBERGER

FREEZE-PAK INSTANT PIPE FREEZING KIT

OPERATING INSTRUCTIONS: PLEASE READ CAREFULLY BEFORE STARTING WORK.

- Turn off all taps and central heating pumps.
- Turn off all water heaters.
- Water must be cold and still before freezing.
- Position jacket around pipe with the seam uppermost.
- Secure tightly to pipe with cable ties supplied.
- Insert feed tube in nozzle of can and through the access hole in the freezer jacket.
- Holding the can upright, inject Quick-Freeze into jacket.
- Should liquid refrigerant appear, pause briefly and allow to evaporate. Then restart.
- Inject the correct amount according to the table shown. Wait at least 10 minutes to allow ice plug to form.
- Should the water be treated with an inhibitor or anti-freeze wait for a further 3-4 minutes.

Pipe Diameter		Cylinder	
Copper	Steel/Lead/Plastic	300g	500g
8, 10, 12 mm	1/4"-3/8"	1	1/2
15 mm	1/2″	1	1/2
22 mm	3/4″	-	1
28 mm	1″	-	1









- A horizontal pipe is easier to freeze but if a vertical pipe requires freezing, use cable ties around the base and ensure the bottom of the freezing jacket is tightly sealed with tape.
- Insert Quick-Freeze from the top.
- Ensure jacket is at least 250mm from work point.
- The ice plug should last up to 30 minutes (dependent on water and room temperature).
- Top up with Quick-Freeze as necessary.
- Ensure you have sufficient spare Quick-Freeze to complete the work.

CAUTION

- Pressurised container protect from sunlight.
- Do not expose this container to temperatures exceeding 50°C. • Do not pierce or burn even after use.
- Do not spray onto a naked flame or any incandescent material.
- Store in a safe place and keep out of reach of children.
- Avoid contact with skin and eyes.
- This product will freeze skin tissue.
- Do not inhale gas, fumes, vapour or spray.
- If swallowed seek immediate medical advice and attention and show this label to the medic.



ROTHENBERGER (UK) LIMITED

2 Kingsthorne Park, Henson Way • Kettering, Northants NN16 8PX Tel: (01536) 310300 • Fax: (01536) 310600 • e-mail: info@rothenberger.co.uk